EarthCo Driveway Repair

DESCRIPTION

EarthCo Driveway Repair is a simple, easy to use system for repairing and maintaining asphalt as well as concrete surfaces. This engineered cementitious material utilizes the most current advances in mix design, modern fiber technology and proprietary chemical technology to produce a stronger, longer lasting solution for pothole repair.

TOOLS NEEDED

- Broom or leaf blower
- Mixer with paddle (Larger and more powerful mixers and paddles are better, especially for larger mixes)
- Trowel

SURFACE PREPARATION

For maximum adhesion, remove any loose dirt, gravel or asphalt from the hole. If there is water in the hole, attempt to remove as much as possible. Do not apply when there is significant water in the hole or when the surface is extremely wet.

MIXING

Shake the EarthCo liquid modifier and pour it into the pail or other mixing container. Pour approximately one quarter of the bag of dry mix into the container and mix. Slowly add the remaining dry mix into the container until you achieve the desired viscosity. (The mix should be able to be troweled without significant effort.) You may not need to add all of the dry mix. Continue to mix 4 to 5 minutes after all the dry mix has been inserted. If using over asphalt, add the bag of powdered pigment and continue to mix. If using for concrete, do NOT use the pigment.

If after following these steps, you determine that due to either weather conditions or other circumstances that the mix is still too stiff, you may add small amounts of water until the mix is the desired consistency. However, adding too much water can slow the cure and weaken the mix and/or cause cracking.

If you find that you have made the mix too liquid, let the mix stand for a couple of minutes before applying.

APPLICATION

After properly mixing, pour the mix into the pothole, spreading the mixture evenly over the bottom of the hole and fill to the top. If the hole is large and another batch mix is required to complete filling the hole, fill the bottom of the hole first and then apply another layer (from the next batch over the first). Trowel the top of the material to a smooth surface. Although you can fill depths up to seven inches, it is less expensive to use gravel, stone, or any other stable aggregate as a filler and then apply the mix in the top two inches.

LIMITATIONS

Do not allow the Modifier to freeze. Apply in temperatures between 40° and 90° F. Installation is not recommended on asphalt that has been poured or resealed within 12 months. For safety purposes, always follow OSHA recommendations such as wearing safety glasses gloves and a dust mask or respirator.

WARRANTY

Notice of Limited Warranty: The company warrants this product to be of merchantable quality when used or applied in accordance with the instructions hereon. This product is not warranted as suitable for any purpose or use other than the general purpose for which it is intended. The color is not warranted to match existing asphalt or concrete. Liability under this warranty is LIMITED to the replacement of its product (as purchased) if found to be defective or at the shipping companies' option, to refund the purchase price. In the event of a claim under this warranty, notice must be given in writing to EarthCo at: 15250 Citrus County Drive, Dade City, FL 33523.

THIS WARRANTY IS ISSUED AND ACCEPTED IN LIEU OF ALL OTHER EXPRESS WARRANTIES AND EXPRESSLY EXCLUDES LIABILITY FOR CONSEQUENTIAL DAMAGES.

DESCRIPCION

EarthCo Driveway Repair es disenado para reparar y mejorar esteticamente la superficie de asphalto y cemento. Este material de cement utiliza los avancemas recientes en el diseno de la mezlca, la tecnologia de fibra moderna y tecnologia de quimico patentado, para producer una solucion para la reparacion de baches mas fuerte y duradera.

HERRAMIENTAS NECESARIAS

- Escoba o soplader de hojas
- Mezclador con la pagaya (Mezcladores y palas mas grandes y mas potentes son mejores, especialmente para las mezclas mas grandes.)
- Palota

PREPERACION DE SUPERFICIE

Para obtener la máxima adhesión, elimine cualquier suciedad, grava o asfalto en el agujero. Si hay agua en el agujero, trate de eliminar la mayor cantidad posible. No aplique si hay una cantidad significativa de agua en el hoyo o cuando el superficie está muy mojado.

MEZCLANDO

Agite bien el EarthCo aditivo y vierta en un balde u otro recipiente. Vierta aproximadamente un cuarto de la bolsa en un recipiente y mezcle. Poco a poco agregue el resto de la mezcla seca en el recipiente mintiendo la humedad para alcanzar la viscosidad deseada. Es posible que no necesite añadir todo de la mezcla seca. Continúe mezclando para 4 a 5 minutos después de que se ha insertado toda la mezcla seca. (Debe ser capaz de manejarse la mezcla con una llana, sin gran esfuerzo.) Si usted encuentra que usted ha hecho de pigmento en polvo y continuar mezclando. Si se utiliza para reparar el hormigon no incluia el pigmento.

Si después de seguir estos pasos Ud. determine que, debido a las condiciones del tiempo u otras circunstancias, la mezcla está demasiada rígida, pueda añadir agua adicionales. Sin embargo, la adición de demasiada agua puede retrasar la curación y debilitar a la mezcla y / o causar grietas.

Si encuentras que tienes hecho mezcla demaslado liquid, dejar la mezcla reposar unos minutos antes de aplicar.

APLICACIÓN

Después de mezclar adecuadamente la química, vierta la mezcla en el bache, unte la mezcla uniformemente sobre el fondo del agujero y llene hasta la parte superior. Si el agujero es grande y se requiere una otra mezcla de lotes para terminar de llenar el hueco, llene el fondo del agujero y luego aplique otra capa (de la hornada siguiente sobre la primera). Con una llana, alise la parte superior de la superficie. Aunque puede utilizar el la mezcla para llenar profundidades de hasta siete pulgadas, es menos costoso si utilice grava, piedras, o cualquier otro agregado estable como un relleno y luego aplique el la mezcla en las dos pulgadas superiores, más o menos.

LIMITACIONES

No permita que la modificadora se congele. Aplique a temperaturas entre 40 ° y 90 ° F Instalación no se recomienda en el asfalto que ha sido derramado o se volvió a cerrar en el plazo de 12 meses. Por razones de seguridad, siempre siga las recomendaciones de OSHA tales como el uso de gafas de seguridad, guantes y una mascara de polvo o respirador.

GARANTIA

Notificación de Garantía Limitada: EarthCo garantiza que este producto es de calidad comercial si se utilice o aplique en conformidad con las instrucciones sobre esto. Este producto no está garantizado como adecuado para cualquier fin o uso que no sea el objetivo general para el que fue concebido. El color no es guarantia para analizar cualquier asphalto o concreto existente. La responsabilidad de esta garantía se limita a la sustitución de su producto (tal como se compró) en caso de que esté defectuoso o, a opción de las navieras, reembolsar el precio de compra. En el caso de una reclamación bajo esta garantía, se debe dar aviso por escrito a: 15250 Citrus County Drive, Dade City, FL 33523.

ESTA GARANTÍA ESTA EXPEDIDOY ACEPTADO EN LUGAR DE CUALQUIER OTRA GARANTÍA EXPRESAY EXPRESAMENTE EXCLUYE RESPONSABILIDAD POR DAÑOS CONSECUENCIALES.

powered by carpenterstone technology

RINSE AND RECYCLE
ENJUAGUE Y RECICLE

EarthCo Enterprises
15250 Citrus County Drive
Dade City, FL 33523